

FGF9 ELISA Kit (Human) (OKBB00144)

Instruction for Use

For the quantitative measurement of Human FGF9 in cell culture supernatants, serum and plasma (heparin, EDTA).

This product is intended for research use only.



Table of Contents

1.	Background	2
	Assay Summary	
3.	Precautions	3
4.	Storage and Stability	3
5.	Kit Components	3
6.	Required Materials Not Supplied	3
7.	Technical Application Tips	4
8.	Reagent Preparation	4
9.	Sample Preparation	6
10.	Assay Procedure	7
11.	Calculation of Results	8
12.	Typical Expected Data	8
13.	Technical Resources	.10



1. Background


Principle

Aviva Systems Biology FGF9 ELISA Kit (Human) (OKBB00144) is based on standard sandwich enzyme-linked immune-sorbent assay technology. A mouse monoclonal antibody specific for FGF9 has been pre-coated onto 96-wellplate (12 x 8 Well Strips). Standards (sf21, M1-S208) and test samples are added to the wells and incubated. After washing, abiotinylated polyclonal goat detector antibody specific for FGF9 is added, incubated and followed by washing. Avidin-Biotin-Peroxidase Complex is then added, incubated and unbound conjugate is washed away. An enzymatic reaction is visualized through the addition of TMB substrate which is catalyzed by HRP to produce a blue color product that changes yellow after adding acidic stop solution. The density of yellow coloration read by absorbance at 450 nm and is quantitatively proportional to the amount of sample Human FGF9 captured in well.

Background

Fibroblast growth factor-9 (FGF-9) is a steroid-regulated mitogen and survival factor for nerve and mesenchymal cells.1 The human FGF-9 cDNA cloned by using oligonucleotide probes encodes a polypeptide consisting of 208 amino acids. Sequence similarity to other members of the FGF family has been estimated to be around 30%.2 FGF-9 is an autocrine estromedin endometrial stromal growth factor that plays roles in cyclic proliferation of uterine endometrial stroma.3 FGF9 is produced and secreted by the prostatic stromal cells. It is a potent mitogen for both prostatic epithelial and stromal cells in culture. FGF9 is an abundant secreted growth factor that can act as both a paracrine mitogen for epithelial cells and an autocrine mitogen for stromal cells. Overexpression of this paracrine and autocrine growth factor may play an important role in the epithelial and stromal proliferation in benign prostatic hyperplasia.4 As a result of glycosylation, the molecular mass is 25-27KDa.

2. Assay Summary





3. Precautions

- Read instructions fully prior to beginning use of the assay kit.
- Any deviations or modifications from the described method or use of other reagents could result in a reduction of performance.
- Reduce exposure to potentially harmful substances by wearing personal protective lab equipment including lab coats, gloves and glasses.
- For information on hazardous substances included in the kit please refer to the Material Safety Data Sheet (MSDS).

4. Storage and Stability

• Upon receipt store kit at 4°C for 6 months or -20°C for 12 months. Avoid multiple freeze/thaw cycles.

5. Kit Components

• The following reagents are the provided contents of the kit.

Description	Quantity
96-Well plate Pre-coated with Anti-Human FGF9 Antibody	1 (12 x 8 Well Strip)
Lyophilized Recombinant Human FGF9 standard	10 ng/tube×2
100X Biotinylated Anti-Human FGF9 Antibody	130 μL
100X Avidin-Biotin-Peroxidase Complex (ABC)	130 µL
Sample Diluent Buffer	30 mL
Antibody Diluent Buffer	12 mL
ABC Diluent Buffer	12 mL
TMB Color Developing Agent	10 mL
TMB Stop Solution	10 mL
10X Wash Buffer	30 mL

6. Required Materials Not Supplied

- Microplate reader capable of reading absorbance at 450 nm.
- Automated plate washer (optional).
- \bullet Pipettes capable of precisely dispensing 0.5 μL through 1 mL volumes of aqueous solutions.
- Pipettes or volumetric glassware capable of precisely measuring 1 mL through 100 mL of aqueous solutions.
- New, clean tubes and/or micro-centrifuge tubes for the preparation of standards or samples.
- Absorbent paper or paper toweling.
- Distilled or deionized ultrapure water.



7. Technical Application Tips

- Do not mix or substitute components from other kits.
- To ensure the validity of experimental operation, it is recommended that pilot experiments using standards and a small selection of sample dilutions to ensure optimal dilution range for quantitation.
- Samples exhibiting OD measurements higher than the highest standard should be diluted further in the appropriate sample dilution buffers.
- Inspect all reagents prior to use. Components should contain no particulates or cloudiness and should be colorless.
- Prior to using the kit, briefly spin component tubes to collect all reagent at the bottom.
- Replicate wells are recommended for standards and samples.
- Cover microplate while incubating to prevent evaporation.
- •Do not allow the microplate wells dry at any point during the assay procedure.
- Do not reuse tips or tube to prevent cross contamination.
- •Avoid causing bubbles or foaming when pipetting, mixing or reconstituting.
- Completely remove of all liquids when washing to prevent cross contamination.
- Prepare reagents immediately prior to use and do not store, with the exception of the top standard.
- Equilibrate all materials to ambient room temperature prior to use (standards exception).
- For optimal results in inter- intra-assay consistency, equilibrate all materials to 37°C prior to performing assay (standards exception) and perform all incubations at 37°C.
- Pipetting less than 1 µL is not recommended for optimal assay accuracy.
- Once the procedure has been started, all steps should be completed without interruption. Ensure that all reagents, materials and devices are ready at the appropriate time.
- Incubation times will affect results. All wells should be handled in the same sequential order and time intervals for optimal results.
- Samples containing precipitates or fibrin strands or which are hemolytic of lipemic might cause inaccurate results due to interfering factors.

8. Reagent Preparation

• Equilibrate all materials to room temperature prior to use and use prepare immediately prior to use.

8.1 1X Biotinylated Anti-Human FGF9 Antibody

- 8.1.1 Prepare the **1X Biotinylated Anti-Human FGF9 Antibody immediately** prior to use by diluting the **100X Biotinylated Anti-Human FGF9 Antibody** 1:100 with Antibody Diluent Buffer.
- 8.1.2 For each well to be used in the experiment prepare 100 μ L by adding 1 μ L of **100X Biotinylated** Anti-Human FGF9 Antibody to 99 μ L Antibody Diluent Buffer.
- 8.1.3 Mix thoroughly and gently. Hold no longer than 2 hours prior to using in procedure.

8.2 1X Avidin-Biotin-Peroxidase Complex (ABC)

- 8.2.1 Prepare the **1X Avidin-Biotin-Peroxidase Complex (ABC)** immediately prior to use by diluting the **100X Avidin-Biotin-Peroxidase Complex (ABC) 1:100** with **ABC Dilution Buffer**.
- 8.2.2 For each well to be used in the experiment prepare 100 μ L, by adding 1 μ L of **100X Avidin-Biotin-Peroxidase Complex (ABC)** to 99 μ L ABC Dilution Buffer.
- 8.2.3 Mix thoroughly and gently. Hold no longer than 2 hours prior to using in procedure.



8.3 FGF9 Assay standards

- 8.3.1 Prepare the FGF9 standards no greater than 2 hours prior to performing experiment. standards should be held on ice until use in the experiment.
- 8.3.2 Reconstitute one of the provided 10 ng Lyophilized Recombinant Human FGF9 standard. Use one for each experiment. Prepare a stock 10,000 pg/mL Human FGF9 standard by reconstituting one tube of Lyophilized Recombinant Human FGF9 standard as follows:
 - 8.3.2.1 Gently spin or tap the vial to collect all material at the bottom.
 - 8.3.2.2 Add 1 mL of Sample Diluent Buffer to the vial.
 - 8.3.2.3 Seal then mix gently and thoroughly.
 - 8.3.2.4 Leave the vial to sit at ambient temperature for 10 minutes.
- 8.3.3 Prepare a set of seven serially diluted standards as follows:
 - 8.3.3.1 Label tubes with numbers 1 8.
 - 8.3.3.2 Add 300 μ L of **Sample Diluent Buffer** to Tube #'s 1 7.
 - 8.3.3.3 Prepare a **4,000 pg/mL standard #1** in by adding 400 μL of the 10,000 pg/mL reconstituted **Human FGF9 standard** to 600 μL of **Sample Diluent Buffer** in Tube#1. Mix gently and thoroughly.
 - 8.3.3.4 Prepare **standard #2** by adding 300 μL of **4,000 pg/mL standard#1** from Tube #1 to Tube #2. Mix gently and thoroughly.
 - 8.3.3.5 Prepare **standard #3** by adding 300 μL of **standard #2 from** Tube #2 to Tube #3. Mix gently and thoroughly.
 - 8.3.3.6 Prepare further serial dilutions through Tube #7. Reference the table below as a guide for serial dilution scheme.
 - 8.3.3.7 Tube #8 is a blank standard (only **Sample Diluent Buffer**), which should be included with every experiment.

Standard Number (Tube)	Sample To Dilute	Volume standard (μL)	Volume Sample Diluent Buffer (µL)	Total Volume (μL)	Final Concentration
1	10,000 pg/mL of Human FGF9 standard	400	600	1,000	4,000 pg/mL
2	Tube #1	300	300	600	2,000 pg/mL
3	Tube #2	300	300	600	1,000 pg/mL
4	Tube #3	300	300	600	500 pg/mL
5	Tube #4	300	300	600	250 pg/mL
6	Tube #5	300	300	600	125 pg/mL
7	Tube #6	300	300	600	62.5 pg/mL
8	NA	0	300	300	0.0 (Blank)





8.4 1X Wash Buffer

- 8.4.1 Add 270 mL of ultra-pure water to a clean > 500 mL bottle or other vessel.
- 8.4.2 Add the entire 30 mL contents of the **10X Wash Buffer** bottle to the water.
- 8.4.3 Seal and mix gently by inversion. Avoid foaming or bubbles.
- 8.4.4 Store the **1X Wash Buffer at** room temperature until ready to use in the procedure. Store the prepared **1X Wash Buffer** at 4°C for no longer than 1 week. Do not freeze.

8.5 Microplate Preparation

- Micro-plates are provided ready to use and do not require rinsing or blocking.
- Unused well strips should be returned to the original packaging, sealed and stored at 4°C.
- Equilibrate microplates to ambient temperatures prior to opening to reduce potential condensation.

9. Sample Preparation

9.1 Sample Preparation and Storage

- Store samples to be assayed at 2-8°C for 24 hours prior being assayed.
- For long term storage, aliquot and freeze samples at -20°C. Avoid repeated freeze-thaw cycles.
- · Clear samples by centrifugation as follows:
 - Cell culture supernatants Remove particulates by centrifugation, assay immediately or aliquot and store samples at -20°C.
 - **Serum** Allow the serum to clot in a serum separator tube (about 4 hours) at room temperature. Centrifuge at approximately 1,000 x g for 15 min. Analyze the serum immediately or aliquot and store samples at -20°C.
 - **Plasma** Collect plasma using heparin or EDTA as an anticoagulant. Centrifuge for 15 min at 1,500 x g within 30 min of collection. Assay immediately or aliquot and store samples at -20°C.

9.2 Sample Dilution

Target protein concentration must be estimated and appropriate sample dilution selected such that the final target protein concentration falls near the middle of the assay linear dynamic range.

- Prepare 150 µL sample for each replicate to be assayed.
- Dilute samples with Sample Diluent Buffer.
- · Mix diluted samples gently and thoroughly.
- Pipetting less than 2 µL is not recommended for optimal assay accuracy.
- Refer to the following table for recommended sample dilution guidelines based on the dynamic range of this kit:

Estimated Sample T	arget Concentration	Dilution Level	Sample Volume For Two Replicates	Sample Diluent Buffer For Two Replicates	
High Concentration	40-400 ng/mL	1:100	3 µL	297 μL	
Medium Concentration	4-40 ng/mL	1:10	25 μL	225 μL	
Low Concentration	62.5-4,000 pg/mL	1:2	100 μL	100 μL	
Very Low Concentration ≤ 62.5 pg/mL		1:2 or No Dilution	=	ı	



10. Assay Procedure

- Equilibrate all reagents and materials to ambient room temperature prior to use in the procedure.
- To control for small potential variations in micro well-plate and day to day ambient temperature fluctuations, equilibrate all reagents prior to use and perform all incubation steps at to 37°C for optimal consistency and reproducibility.
- **10.1** Add 100 μL of serially titrated standards, diluted samples or blank into wells of the pre-coated well plate. At least two replicates of each standard, sample or blank is recommended.
- **10.2** Cover the plate with the well plate lid and incubate for 90 minutes.
- **10.3** Remove the plate lid and discard the liquid in the wells by rigorously flicking into an acceptable waste receptacle.
- **10.4** Gently blot any remaining liquid from the wells by tapping inverted on the benchtop onto paper toweling. Do not allow the wells to completely dry at any time.
- **10.5** Add 100 μL of prepared **1X Biotinylated Anti-Human FGF9 Antibody to each well.**
- **10.6** Cover with the well-plate lid and Incubate for 60 minutes.
- **10.7** Wash plate 3 times with **1X Wash Buffer as** follows:
 - 10.7.1 Discard the liquid in the wells by rigorously flicking into an acceptable waste receptacle.
 - 10.7.2 Gently blot any remaining liquid from the wells by tapping inverted on the benchtop onto paper toweling. Do not allow the wells to completely dry at any time.
 - 10.7.3 Add 300 μL of **1X Wash Buffer** to each assay well.
 - 10.7.4 Incubate for 1 minute.
 - 10.7.5 Repeat steps 10.7.1 through 10.7.4 two more times.
- **10.8** Add 100 μL of prepared **1X Avidin-Biotin-Peroxidase Complex (ABC) into** each well and incubate for 30 minutes.
- **10.9** Wash plate 5 times with **1X Wash Buffer as** follows:
 - 10.9.1 Discard the liquid in the wells by rigorously flicking into an acceptable waste receptacle.
 - 10.9.2 Gently blot any remaining liquid from the wells by tapping inverted on the benchtop onto paper toweling. Do not allow the wells to completely dry at any time.
 - 10.9.3 Add 300 µL of 1X Wash Buffer to each assay well.
 - 10.9.4 Incubate for 1 minute.
 - 10.9.5 Repeat steps 10.9.1 through 10.9.4 **four** more times.
- **10.10** Add 90 μL of **TMB Color Developing Agent** to each well and incubate in the dark for 15-20 minutes. (NOTE: optimal incubation time must be determined by the user. Optimal development can be visualized by blue shading in the top four standard wells, while the remaining standards are still clear.)
- 10.11 Add 100 µL of TMP Stop Solution to each well. Well color should change to yellow immediately.
- **10.12** Read the O.D. absorbance at 450 nm with a standard microplate reader within 30 minutes of stopping the reaction in step 10.11.



11. Calculation of Results

For analysis of the assay results, calculate the **Relative OD**₄₅₀ for each test or standard well as follows:

The standard curve is generated by plotting the mean replicate Relative OD_{450} of each standard serial dilution point vs. the respective standard concentration. The Human FGF9 concentration contained in the samples can be interpolated by using linear regression of each mean sample **Relative OD**₄₅₀ against the standard curve. This is best achieved using curve fitting software.


Note: if the samples measured were diluted, multiply the derived mean sample concentration by the dilution factor for a final sample concentration.

12. Typical Expected Data

12.1 Typical absorbance values. Expected absorbance for standards when TMB incubation is performed for 20 minutes at 37°C and measured at OD₄₅₀.

Standard Number	8	7	6	5	4	3	2	1
standard Concentration (pg/mL)	0	62.5	125	250	500	1000	2000	4000
OD450	0.087	0.097	0.115	0.145	0.247	0.500	1.026	2.188

12.2 Typical standard curve. This standard curve is for demonstration purposes only. An assay specific standard curve should be performed with each assay.





12.3 General Specifications

General Specificiations						
Range	62.5 pg/mL -4,000 pg/mL					
Sensitivity	< 15 pg/mL (Derived by linear regression of OD ₄₅₀ of the Mean Blank + 2xSD)					
Specificity	Natural and recombinant Human FGF9 UniProt ID: P31371					
Cross-Reactivity	No detectable cross-reactivity with other relevant proteins					
Recovery	-					
Linearity	-					

12.4 Reproducibility

	Intra-Assay			Intra-Assay Inter-Assay			
Sample ID	1	2	3	1	2	3	
n =	16	16	16	24	24	24	
Mean Measured Concentration (pg/mL)	256	1145	2278	247	1242	2226	
Standard Deviation	11.52	43.51	75.17	18.28	80.73	135.8	
Consistency (%CV)	4.5	3.8	3.3	7.4	6.5	6.1	



13. Technical Resources

13.1 References

- 13.1.1 Wing LY, Chuang PC, Wu MH, Chen HM, Tsai SJ. Expression and mitogenic effect of fibroblast growth factor-9 in human endometriotic implant is regulated by aberrant production of estrogen. J Clin Endocrinol Metab. 2003 Nov;88(11):5547-54.
- 13.1.2 Miyamoto, M.; Naruo, K.-I.; Seko, C.; Matsumoto, S.; Kondo, T.; Kurokawa, T. Molecular cloning of a novel cytokine cDNA encoding the ninth member of the fibroblast growth factor family, which has a unique secretion property. Molec. Cell. Biol. 13: 4251-4259, 1993.
- 13.1.3 Tsai SJ, Wu MH, Chen HM, Chuang PC, Wing LY. Fibroblast growth factor-9 is an endometrial stromal growth factor. Endocrinology. 2002 Jul;143(7):2715-21.
- 13.1.4 Giri D, Ropiquet F, Ittmann M. FGF9 is an autocrine and paracrine prostatic growth factor expressed by prostatic stromal cells. J Cell Physiol. 1999 Jul;180(1):53-60.

13.2 Technical Support

USA

Aviva Systems Biology, Corp. 5754 Pacific Center Blvd, Suite 201 San Diego, CA 92121

Phone: 858-552-6979 Toll Free: 888-880-0001 Fax: 858-552-6975

Technical support: techsupport@avivasysbio.com

China

Beijing AVIVA Systems Biology 6th Floor, B Building, Kaichi Tower #A-2 Jinfu Road. Daxing Industrial Development Zone Beijing, 102600, CHINA

Phone: (86)10-60214720 Fax: (86)10-60214722

E-mail: support@avivasysbio.com.cn

中国地址:北京大兴工业开发区金辅路甲 2 号凯驰大厦 B座 6层 (102600)

电话: 010-60214720/21 传真: 010-60214722

产品售前咨询及销售: sales@avivasysbio.com.cn售后及技术支持: support@avivasysbio.com.cn